

Good Sense Dispenser Plus

Automatic Odour Control and Air Freshening System

Description


Good Sense Dispenser Plus is a system which automatically sprays high quality air care products via one compact, modern and lockable dispenser. It is easily fitted to any surface, either with integral self-adhesive pads or with the screws provided. In combination with unique Good Sense fragrance cartridges it ensure every room smells fresh and inviting for an unforgettable experience - all day, every day.

Key properties

- Easy to install, mounting hardware are provided with each device
- Battery powered
- Adjustable settings, easy maintainance, and a keyless locking system
- Photocell feature allows the dispenser to simply go into a sleep mode whenever the room is put into darkness
- Choice of fragrance varieties for effective malodour removal containing patented Odour Neutralising Technology (O.N.T.)

Benefits

- Easily fits to any surface, either with integral self-adhesive pads or with the screws provided and supplied with 2 AA batteries, lasting up to 18 months
- Flexibility to set spray intervals to every 30 min, 1, 2 or 3 hours and due to the photocell feature no more wasted sprays over night or when the area is not used.
- LED light gives a clear indication when fragrance cartridges or batteries need to change, reducing maintenance time
- Keyless locking system to ensure that the cartridge is well protected without the risk of lost keys
- Use of fragrance cartridges incorporating Odour Neutralising Technology (O.N.T.) which doesn't mask malodors but chemically destroys them to enhance the perception



Good Sense Dispenser Plus

Use instructions

Installation

- Ensure the dispenser is at least mounted 15.24 cm below the ceiling
- The odour control system is most effective when located in high traffic areas e.g. near urinals or toilets.
- Always follow the mounting instruction provided with the dispenser

Insert Cartridge

- Insert the tip of the refill cartridge into the nozzle inside the dispenser cover
- Slide the base of the refill cartridge slightly sideways and twist it to align into the slot
- Adjust the switch to the selected spray interval
- Optional, turn on the photocell by moving the switch to the “on” position
- Press the reset button
- Place the cover back on the backplate

Maintenance

- Change the refill cartridge when the LED light flashes red
- Unlock the dispenser cover
- Lift the cover up and off the wall unit
- Gently lift the old cartridge upwards and slide its base out first
- Insert a new cartridge as described above

Change batteries when the LED stops flashing. Follow the instruction as provided with the user manual

Technical data

Appearance: White dispenser (Size LxWxH: 125x97.0x193 mm)

The above data is typical of normal production and should not be taken as a specification.

Product compatibility

Good Sense Dispenser Plus is specifically engineered to accommodate 20 ml Good Sense Refill cartridges, which feature a uniquely designed shape that ensures compatibility exclusively with this dispenser and contain high-quality fragranced aerosol spray.

Available pack sizes

The Good Sense Dispenser Plus is supplied as a single unit, while the Good Sense Refill cartridges are packaged in selling units of 12 pieces.

www.solenis.com

© 2026 Solenis LLC. All Rights Reserved. Rev.25/02/2026 en (K03091)